

## DAHua camera People and vehicles movement detection Audible alarm

1. Log in to the camera web terminal, click "setting-Event-Video Detection-motion Detection".



- ① Click "enable" turn on Motion Detection.
- ② Turn on "Audio linkage" and setting audio file.
- ③ Turn on "Warming light ".

2. Click "Setting- Event -Smart Motion Detection ",check "Enable", Select check "Human" and "motor Vehicle",click "Save" to apply.



3. Click "Setting -Camera - Audio -Audio -Speaker Volume" volume adjustment.

IP Camera		Live Playback Setting Alarm
Camera 2	Audio 4 Alarm Audio	
> Conditions > Video	Encode	
> Audio 3	Main Stream	
Network	Enable	
Event	Encode Mode G.711A V	
Storage	Sampling Frequency 8000	
<ul> <li>System</li> <li>Information</li> </ul>	Sub Stream	
	Enable Sub Stream 1	
	Encode Mode G.711A V	
	Sampling Frequency 8000	
	Attribute	
	Audioln Type	
	Noise Filter Disable	
	Microphone Volume	
	Speaker Volume - + 100 5	
	Default Refresh Save	

4. The live screen will be a light and sound alarm sign.

