


Hikvision camera shutter settings

1. Open IE browser .enter camera IP in the search bar and log in camera web.



2. Click "Configuration-Image-Display Settings-Exposure Settings", “Exposure Time” function to adjust shutter speed

