


Focal length self-check setting

1. Login camera web page.



2. Call the preset position 111, then call the preset position 222, wait for 15 minutes after the self-check is completed, and then call the preset position 34.



3. Factory Reset.

