

PTZ Factory default

Note: The PTZ of the device may be offset during transportation or installation. You can reset the PTZ in the following ways

Log in to the web page of the camera, enter 82 into the preset box, and click Call to reset

