



# Turn on camera onvif permissions

1. Log in to the camera web.



- 2.
3. Turn on the camera's onvif permissions and add an onvif user.(it is recommended that the account password is the same as the camera's login account password).



### Add user

User Name:  ✓

Digits, lower-case letters, upper-case letters, and special characters (#\$%&()\*+,-./:<=>?@[^\_`{}~ space) are allowed.

Password:  ✓

8 to 16 characters allowed, including upper-case letters, lower-case letters, digits and special characters (#\$%&()\*+,-./:<=>?@[^\_`{}~ space). At least two of above mentioned types are required.

Confirm:  ✓

Level:  Media user  
 Operator  
 Administrator

OK Cancel